

# EtherNet/IP™ User Manual

# EtherNet/IP®

## Contents

Preface .....	3
Terms of use .....	4
Revision overview.....	5
Connection diagram .....	6
Applicable for: LA33, LA36, LA37, LA76 and LA77 .....	6
Applicable for: LC3 IC.....	7
I/O specifications.....	8
Parallel.....	9
Getting started .....	11
Power supply.....	11
Configuration.....	11
Parameters to be verified by Actuator Connect™ .....	12
Adapter settings .....	13
Command examples .....	14
General run prerequisites.....	14
Run the actuator outwards .....	15
Run the actuator to target position (150 mm).....	16
Clear error in overcurrent situation.....	17
Assembly data .....	18
Assembly Data Output.....	18
Assembly Data Input.....	19
Assembly Data Input (Parallel feedback).....	21
Error codes .....	23
Parallel error codes.....	24
Contacts.....	26

## Preface

Dear User,

We are delighted that you have chosen a LINAK® product.

LINAK systems are high-tech products based on many years of experience in the manufacture and development of actuators, lifting columns, desk frames, electric control boxes, controls, batteries, accessories and chargers.

This User Manual does not address the end user. It is intended as a source of information for the equipment or system manufacturer only, and it will tell you how to install, use and maintain your LINAK electronics. The manufacturer of the end product has the responsibility to provide a User Manual, where relevant safety information from this manual is passed on to the end user.

We are convinced that your LINAK product/system will give you many years of problem-free operation.

Before our products leave the factory, they undergo both function and quality testing. Should you, nevertheless, experience problems with your product/system, you are always welcome to contact your supplier.

LINAK subsidiaries and some distributors situated all over the world have authorised service centres, which are always ready to help you. Locate your local contact information on the back page.

LINAK provides a warranty on all products. (See warranty section).

This warranty, however, is subject to correct use in accordance with the specifications, maintenance being done correctly, and any repairs being carried out at a service centre, which is authorised to repair LINAK products.

Changes in installation and use of LINAK systems can affect their operation and durability. The products may only be opened by authorised personnel.

This User Manual has been written based on the present technical knowledge. LINAK reserves the right to carry out technical modifications and keeps the associated information updated.

**LINAK A/S**

## Terms of use

LINAK® takes great care in providing accurate and up-to-date information on its products. However, the user is responsible for determining the suitability of LINAK products for a specific application.

Due to continual development, LINAK products are subject to frequent modifications and changes. LINAK reserves the rights to conduct modifications, updates, and changes without any prior notice. For the same reason, LINAK cannot guarantee the correctness and actual status of imprinted information on its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates.

All sales are subject to the 'Standard Terms of Sale and Delivery for LINAK A/S' available on LINAK websites.

LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

## Revision overview

### Edition 3

LA14 and LA25 removed	Page 6
LA33 added	Page 6
Information about separate supplies added	Page 10
Adapter settings updated	Page 13
'Command examples' section updated	Page 14-16
'Assembly data' section added	Page 17-20

### Edition 2

Item number for cable kit added	Page 6-7
'Manual run' changed to 'Extends actuator' and 'Retracts actuator'	Page 6-8
'Service interface' changed to 'Parallel communication'	Page 6-8
'Service interface GND' changed to 'Parallel GND'	Page 6-8
'V DC' added	Page 6-8
Information about separate supplies added	Page 6-8
'Parallel' section updated	Page 9-10
Power supply table updated	Page 11
'Parameters to be verified by Actuator Connect™' updated	Page 12
'Run out command' changed to 'Command examples'	Page 14
'Communication sequence...' changed to 'Run the actuator outwards'	Page 14

### Edition 1


New document

## Connection diagram

Applicable for: LA33, LA36, LA37, LA76 and LA77

**BROWN** 24/48 V DC

**BLUE** GND




**1** Extends the actuator

**2** Retracts the actuator

**4\*** Split power supply V DC

**3** Parallel data

**5** Parallel GND




**1** ETH\_TX+

**2** ETH\_RX+

**3** ETH\_TX-

**4** ETH\_RX-



The physical layer conforms to the IEEE 802.3-2018 standard with communication speeds of 10 Mbps and 100 Mbps, respectively. Cable length is reduced to = 100 m without repeater, as determined by IEEE 802.3-2018.

\* Split power supply and motor supply (Brown), which refer to a common GND (Blue).

This approach is used to maintain power on the intelligent part of the actuator. In case the main supply is disconnected, split power supply allows e.g. that the position is maintained. The main supply may be disconnected for reasons related to safety, maintenance or installation.



**Actuator Connect™ is available for EtherNet/IP™ actuators and can be used for:**

Diagnostics, manual run and configuration. The newest version is available online [here](#).



Connect the actuator to Actuator Connect via a USB adapter cable (must be purchased separately) to enable and configure various features.

Item number for cable kit: 0367996

## Connection diagram

Applicable for: LC3 IC

**BROWN** 24/48 V DC

**BLUE** GND




**RED** Extends the actuator

**BLACK** Retracts the actuator

**ORANGE\*** Split power supply V DC

**VIOLET** Parallel data

**WHITE** Parallel GND




**Molex mini-fit  
12-pin**

**1** ETH\_TX+

**3** ETH\_RX+

**2** ETH\_TX-

**6** ETH\_RX-



**RJ45**



The physical layer conforms to the IEEE 802.3-2018 standard with communication speeds of 10 Mbps and 100 Mbps, respectively. Cable length is reduced to = 100 m without repeater, as determined by IEEE 802.3-2018. The wiring conforms to the T-568A standard.

\* Split power supply and motor supply (Brown), which refer to a common GND (Blue).

This approach is used to maintain power on the intelligent part of the actuator. In case the main supply is disconnected, split power supply allows e.g. that the position is maintained. The main supply may be disconnected for reasons related to safety, maintenance or installation.



**Actuator Connect™ is available for EtherNet/IP™ actuators and can be used for:**



Diagnostics, manual run and configuration. The newest version is available online [here](#).



Connect the actuator to Actuator Connect via a USB adapter cable (must be purchased separately) to enable and configure various features.

Item number for cable kit: 0367996

## I/O specifications

Input/Output	Specification	Comments
Description	The communication protocol conforms to the IEEE 802.3-2018 Ethernet standard with communication speeds of 10 Mbps and 100 Mbps.	<b>EtherNet/IP®</b>
Brown	Connect Brown to positive 24/48 V DC	Note: Do not change the power supply polarity on the Brown and Blue wires!  Only for powering the motor driver module. Power supply GND is electrically connected to the housing through a capacitor and resistor in parallel.
Blue	Connect Blue to negative GND	
<b>PIN out</b>	<b>Data cable M12 - 5-pin male</b>	
Pin 1	Extends the actuator	The signal becomes active at: $V_{IN} > 67\%$ of V DC  The signal becomes inactive at: $V_{IN} < 33\%$ of V DC Input current: 10 mA
Pin 2	Retracts the actuator	
Pin 4	Split power supply V DC	Split power supply: 24 V DC with $\approx 28$ mA current consumption. 48 V DC with $\approx 16$ mA current consumption.  The split power supply uses the common GND from the power supply (Blue).  Split power supply is only for powering the communication of the integrated controller.
Pin 3	Parallel data	The Parallel drive function will support up to 8 actuators running simultaneously. It is possible to run Parallel with a main power supply or separate power supplies.  If separate supplies are used, they must have the same potential, and the power supply GND (Blue wires) must be connected in the common ground.
Pin 5	Parallel GND	
<b>PIN in</b>	<b>Data cable M12 - 4-pin female</b>	
Pin 1	ETH_TX+	
Pin 2	ETH_RX+	
Pin 3	ETH_TX-	
Pin 4	ETH_RX-	
<b>PIN in</b>	<b>RJ45 (Only for LC3 IC)</b>	
Pin 1	ETH_TX+	
Pin 3	ETH_RX+	
Pin 2	ETH_TX-	
Pin 6	ETH_RX-	




## Parallel

The industrial LINAK® actuators can be ordered with parallel functionality. If this feature is enabled, it is possible to run up to 8 actuators in a parallel system with just one actuator occupying an Ethernet port connection. The system works as a critical parallel, meaning that all actuators must be present in the system and have the exact same configuration (both mechanical and software functionality).

Below is a checklist to ensure that the system operates as intended:

Action	Description
Set up parallel in Actuator Connect™	Each actuator must be configured to operate in parallel (2-8 actuators). This can be set up using the Actuator Connect tool. <i>Please note: In some cases this is pre-configured from factory.</i>
Wire up the system	The actuators feature internal communication for parallel synchronisation and error codes.
Check cable lengths	Keep the total length of the communication line below 40 meters to avoid communication dropouts. In a parallel system with 8 actuators this would result in signal cable lengths of <5 metres.
Check power supply	The system can be designed with either one main power supply or it can be supplied by individual supplies corresponding to the number of actuators in the system. Please respect actuator specifications regarding voltage level and current consumption! Make sure that the power supplies have a common GND and the same potential.

### Option 1 - A simple parallel setup




In a simple parallel setup there is only one actuator connected to the network. This actuator receives run commands and shares data with the controller. The remaining actuators in the system are only connected to internal parallel communication. This way, the internal communication ensures that the system operates in parallel and stops in case of an obstacle, or when other errors occur on one of the actuators.

The actuators share simple error messages with the master, which can be distributed via the network.

## Parallel

### Option 2 - Bus communication on all actuators



If there is a need for e.g. monitoring the real-time data of each actuator, it is possible to connect all actuators as nodes to the network. This will provide comprehensive usage data, which can be used to enhance performance in the application. Similar to option 1, this requires that all actuators are connected to internal parallel communication.

It is also possible to use two separate power supplies in parallel under the condition that they have the same voltage and wattage output. It is essential that both power supplies share a common ground connection (Blue wire).

## Getting started

This section further describes how to communicate with LINAK® EtherNet/IP™ actuators and contains examples of typical user scenarios and application solutions. All examples include references to registers which are further described in detail below.

### Power supply

EtherNet/IP actuators are available with the following supply voltage range: 24 and 48 V DC. The accepted supply voltage range is specified for the version as shown below:

Supply voltage	Function	Voltage range		
		V <sub>IN</sub>	V <sub>TYP</sub>	V <sub>MAX</sub>
24 V	Motor	18 V	24 V	32 V
	EtherNet/IP communication	10 V	24 V	39 V
48 V	Motor	36 V	48 V	58 V
	EtherNet/IP communication	10 V	48 V	60 V

For more information about wiring/connector, please see the connection diagram.


### Configuration

Before being integrated into a EtherNet/IP system, a few of the actuator parameters must be checked and eventually changed. This preparation is done via the use of the configuration tool Actuator Connect™ and guarantees that the actuator is able to execute basic functionality.

Further fine-tuning may be required to fulfil system or application requirements. Via this tool it is also possible to access historical usage data and real-time monitoring.

#### Valid for LA33, LA36, LA37, LA76 and LA77:

A separate configuration cable (item no. 0367996) is required to use Actuator Connect on a PC. This cable must be connected to the 6-pin and 9-pin connector on the actuator side. On the opposite side, power must be applied to the flying leads, and the USB connector must be inserted into your PC.



For more information about wiring/connector, please see the connection diagram.

**Parameters to be verified by Actuator Connect™**

Parameters	Description
DHCP	DHCP is a client/server protocol that automatically provides an IP address. <b>If enabled: below parameters are not configurable</b>
IP Address	Set the device IP address to a unique address in the network. 192.168.1.10 (Default)
Subnet mask	Set the subnet mask. 255.255.255.0 (default)
Gateway	Set the gateway. 192.168.1.1 (default)

## Adapter settings

Depending on controller (Scanner) there are different ways to configure the adapter settings (Actuator). Some may accept EDS files, and others will need you to input the values manually. EDS file is downloadable at [www.LINAK.com](http://www.LINAK.com)

### Setting up the scanner for adapter manually

Follow the example on the next page to complete the startup procedures necessary for successful communication with a LA36 EtherNet/IP™. Output and Input Assembly are run by Implicit commands, while Configuration Assembly and Diagnostics are run by Explicit commands.

All necessary adapter settings written in the table below can be found in the EDS file.

Adapter Settings (Startup Procedures)		
Parameters	Value	Description
Adapter IP address	192.168.1.10	IP address of the actuator
Vendor ID	1538	LINAK
Product Type	12	Communication adapter
Product Code	36	LA36 (Adjust value according to your product)
Major Revision	1	Revision of adapter
Minor Revision	4	Revision of adapter
RPI (Requested Packet Interval)	100 ms	Update rate
Configuration AssemblyID	151 [0x97]	ID for configuration data
Configuration Assembly Size	0	Length of configuration data in bytes (None in this example)
O->T (Output) AssemblyID	150 [0x96]	ID for Output Assembly data
O->T (Output) Assembly Size	6	Length of Output Assembly data in bytes
T->O (Input) AssemblyID	100 [0x64]	ID for Input Assembly data
T->O (Input) Assembly Size	14	Length of Input Assembly data in bytes

O->T Organizer to Target

T->O Target to Organizer

When the Scanner is configured with the above values, communication should be established. You should now be able to access the "Command details" from AssemblyID 150 (0x96) and "Feedback details" from AssemblyID 100 (0x64).



Users are strongly advised against configuring their assets directly to the public internet. By taking this precautionary measure, the risk of unauthorized and malicious cyber activities from external threats is significantly reduced.

## Command examples

Before the actuator can engage movement, some general prerequisites must be fulfilled. Timing (e.g. when the actuator is still moving), environmental conditions and errors may indicate that the actuator is in a state where further operation is not possible.

### General run prerequisites

Step	Read/Write	Assembly Instance ID*	Action
1	Write	Command details AID 150 [0x96] Byte 0 Byte 1	"Position" must be set to = 64259 [0xFB03] for 'Stop'. To prevent unintended movement it is required to send a 'Stop' command before running the actuator.
2	Write	Feedback status details AID 100 [0x64] Byte 4	"Error Code" must be = 0 [0x00].
3	Write	Feedback status details AID 100 [0x64] Byte 3	"Status Flags" bit 2 (Overcurrent) must be = 0.
4	Write	Feedback status details AID 100 [0x64] Byte 3	"Status Flags" bit 5 (Heartbeat needed) must be = 0.
5	Write	Feedback status details AID 100 [0x64] Byte 3	"Status Flags" bit 6 (Actuator is running outside normal conditions) must be = 0.

\* AID 100 = Feedback / AID 150 = Command

## Run the actuator outwards

Step	Read/Write	Assembly Instance ID*	Action
1		-	Check that general run prerequisites are fulfilled.
2	Write	Command details AID 150 [0x96] Byte 2	<p>"Current" must be set to a value.</p> <p>0-250 [0x00-FA] = Current limit 0.25 A/bit</p> <p>251 [0xFB] = Default current limit set via Actuator Connect™</p> <p>252-255 [0xFC-FF] = Reserved</p>
3	Write	Command details AID 150 [0x96] Byte 3	<p>"Speed" must be set to a value.</p> <p>0-200 [0x00-FA] = Speed 0.5% /bit</p> <p>201-250 [0xC9-FA] = 100% speed</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
4	Write	Command details AID 150 [0x96] Byte 4	<p>"Soft Start" must be set to a value.</p> <p>0-250 [0x00-FA] = Start ramp time 0.05 s/bit</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
5	Write	Command details AID 150 [0x96] Byte 5	<p>"Soft Stop" must be set to a value.</p> <p>0-250 [0x00-FA] = Stop ramp time 0.05 s/bit</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
6	Write	Command details AID 150 [0x96] Byte 0 Byte 1	"Position" must be set to = 64257 [0xFB01] for 'Run out'.
7**	Read	Feedback status details AID 100 [0x64] Byte 3	<p>"Status Flags" bit 3 and bit 1 change to 1 to indicate that:</p> <p>Bit 3 = Actuator is running out</p> <p>Bit 1 = Endstop reached signal out</p>

\* AID 100 = Feedback / AID 150 = Command

\*\* Optional

## Run the actuator to target position (150 mm)

Step	Read/Write	Assembly Instance ID*	Action
1		-	Check that general run prerequisites are fulfilled.
2	Write	Command details AID 150 [0x96] Byte 2	<p>"Current" must be set to a value.</p> <p>0-250 [0x00-FA] = Current limit 0.25 A/bit</p> <p>251 [0xFB] = Default current limit set via Actuator Connect™</p> <p>252-255 [0xFC-FF] = Reserved</p>
3	Write	Command details AID 150 [0x96] Byte 3	<p>"Speed" must be set to a value.</p> <p>0-200 [0x00-FA] = Speed 0.5% /bit</p> <p>201-250 [0xC9-FA] = 100% speed</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
4	Write	Command details AID 150 [0x96] Byte 4	<p>"Soft Start" must be set to a value.</p> <p>0-250 [0x00-FA] = Start ramp time 0.05 s/bit</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
5	Write	Command details AID 150 [0x96] Byte 5	<p>"Soft Stop" must be set to a value.</p> <p>0-250 [0x00-FA] = Stop ramp time 0.05 s/bit</p> <p>251 [0xFB] = Default speed set via Actuator Connect</p> <p>252-255 [0xFC-FF] = Reserved</p>
6	Write	Command details AID 150 [0x96] Byte 0 Byte 1	"Position" must be set to = 1500 [0x05DC] for 'Run to Target Position 150 mm'.
7**	Read	Feedback status details AID 100 [0x64] Byte 3	<p>"Status Flags" bit 3 or bit 4 change to 1 to indicate that:</p> <p>Bit 3 = Actuator is running out</p> <p>Bit 4 = Actuator is running in</p>



## Clear error in overcurrent situation

If an overcurrent occurs, the actuator will be stopped and blocked in that direction until an activation in the opposite direction has been made or the system has been re-powered.

Step	Read/Write	Assembly Instance ID*	Action
1	Read	Feedback status details AID 100 [0x64] Byte 3	Confirm that "Status Flags" bit 2 is = 1 for 'Overcurrent'
2	Write	Command details AID 150 [0x96] Byte 0 Byte 1	"Position" must be set to run in the opposite direction of the blockage Set to = 64257 [0xFB01] for 'Run out' or Set to = 64258 [0xFB02] for 'Run in'
3	Read	Feedback status details AID 100 [0x64] Byte 3	"Status Flags" bits change to 1 to indicate that either: Bit 3 = Actuator is running out Bit 4 = Actuator is running in Bit 1 = Endstop reached out Bit 0 = Endstop reached in

\* AID 100 = Feedback / AID 150 = Command

\*\* Optional

## Assembly data

When controlling the actuator from the EtherNet/IP controller, it is important to understand the input and output data. For EtherNet/IP this is defined by the EDS file. The specific data is described in the tables below.

### Assembly Data Output

Output Assembly Instance ID150 [0x96] Class 1 implicit I/O messaging					
Byte 5 [MSB]	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0 [LSB]
Soft Stop	Soft Start	Speed	Current	Position	

Assembly Instance ID	Byte(s)	Command	Data type	Details	Description	Scaling
150 [0x96]	Byte 0 Byte 1	Position	UINT16	0–64255 [0x0000-FAFF]	Run to position	0.1 mm/bit
				64256 [0xFB00]	Clear Error Codes (see AID 100 [0x64] Byte 4)	
				64257 [0xFB01]	Run out	
				64258 [0xFB02]	Run in	
				64259 [0xFB03]	Stop	
				64260 [0xFB04]	Recovery run out	
				64261 [0xFB05]	Recovery run in	
				64262–65535 [0xFB06-FFFF]	Invalid value, actuator will not run	
	Byte 2	Current	UINT8	0–250 [0x00-FA]	Maximum current limit	0.25 A/bit
				251 [0xFB]	Use default current value	
				252–255 [0xFC-FF]	Invalid value, actuator will not run	
	Byte 3	Speed	UINT8	0–200 [0x00-C8]	Speed	0.5%/bit
				201–250 [0xC9-FA]	Use 100% speed	
				251 [0xFB]	Use default speed value	
				252–255 [0xFC-FF]	Invalid value, actuator will not run	

## Assembly Data Output

Assembly Instance ID	Byte(s)	Command	Data type	Details	Description	Scaling
150 [0x96]	Byte 4	Soft Start	UINT8	0–250 [0x00-FA]	Start ramping time	0.05 s/bit
				251 [0xFB]	Use default soft start value	
				252–255 [0xFC-FF]	Invalid value, actuator will not run	
	Byte 5	Soft Stop	UINT8	0–250 [0x00-FA]	Stop ramping time	0.05 s/bit
				251 [0xFB]	Use default soft stop value	
				252–255 [0xFC-FF]	Invalid value, actuator will not run	

## Assembly Data Input

Input Assembly Instance ID100 [0x64] Class 1 implicit I/O messaging							
Byte 7	Byte 6	Byte 5	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0 [LSB]
AUX Input	Speed		Error Code	Status Flags	Current	Position	

Assembly Instance ID	Byte(s)	Status	Data type	Details	Description	Scaling
100 [0x64]	Byte 0 Byte 1	Position	UINT16	0–64255 [0x0000-FAFF]	Position of the actuator piston	0.1 mm/bit
				64256-65023 [0xFB00-FDFF]	Reserved	
				65024 [0xFE00]	Position lost	
				65025-65535 [0xFE01-FFFF]	Reserved	
	Byte 2	Current	UINT8	0 [0x00]	Not running	0.25 A/bit
				1-250 [0x00-FA]	Measured motor current	
				251-253 [0xFB-FD]	Reserved	
				254 [0xFE]	Fault in current measurement circuit	
				255 [0xFF]	Reserved	

## Assembly Data Input

Assembly Instance ID	Byte(s)	Status	Data type	Details	Description	Scaling
100 [0x64]	Byte 3	Status Flags	UINT8	b0	Endstop reached in	8-bit independent status indicators
				b1	Endstop reached out	
				b2	Overcurrent	
				b3	Running out	
				b4	Running in	
				b5	Communication heartbeat needed	
				b6	Actuator is running outside nominal conditions	
				b7	Reserved. Always high	
	Byte 4	Error Code	UINT8	0 [0x00]	No error detected	8-bit error code showing the currently active error with the highest priority only
				1 [0x01]	'Run' command overruled	
				2 [0x02]	Position sensor	
				3 [0x03]	Overvoltage	
				4 [0x04]	Undervoltage	
				5 [0x05]	Communication sync.	
				6 [0x06]	Endstop switch	
				7 [0x07]	Temperature	
				8 [0x08]	Motor controller	
				9 [0x09]	Internal power supply	
				10 [0x0A]	Internal current measurement	
				11 [0x0B]	Parallel arbitration	
				12 [0x0C]	Position not changing	
				13 [0x0D]	Position initialisation not possible	
				14 [0x0E]	Alone in parallel system	
				15 [0x0F]	Incorrect number in parallel system	

## Assembly Data Input

Assembly Instance ID	Byte(s)	Status	Data type	Details	Description	Scaling
100 [0x64]	Byte 4	Error Code	UINT8	254 [0xFE]	Other internal error (Not specified)	8-bit error code showing the currently active error with the highest priority only
				255 [0xFF]	Other external error (Not specified)	
	Byte 5 Byte 6	Speed	UINT16	0-4015 [0x0000-0FAF]	Speed of actuator piston	0.1 mm/s / bit
				4016-65535 [0x0FB0-FFFF]	Reserved	
	Byte 7	AUX Input	UINT8	b0-b1	Input 1 level	25% VCC / bit
				b2-b3	Input 2 level	
				b4-b5	Reserved	
				b6-b7	Reserved	Always high

## Assembly Data Input (Parallel feedback)

Input Assembly Instance ID100 [0x64] Class 1 implicit I/O messaging Only for parallel feedback					
Byte 13 [MSB]	Byte 12	Byte 11	Byte 10	Byte 9	Byte 8
Status Flags	Error Group	Error Source			

Assembly Instance ID	Byte(s)	Command	Data type	Details	Description	Unit
100 [0x64]	Byte 8 Byte 9 Byte 10 Byte 11	Error Source	UINT32	0 [0x00000000]	No error is active on any actuator in parallel system, or error source ID is irrelevant  ("Parallel start-up" error is reported by an actuator still connected to the system)	32-bit IP address
				1-4294967295 [0x00000001-FFFFFFFF]	IP address of the actuator with highest priority error	

## Assembly Data Input (Parallel feedback)

Assembly Instance ID	Byte(s)	Status	Data type	Details	Description	Unit
100 [0x64]	Byte 12	Error Group	UINT8	0 [0x00]	No error detected	8-bit error code indicating the currently active error of highest priority on any actuator in the parallel system
				1 [0x01]	Current overload	
				2 [0x02]	Hardware	
				3 [0x03]	Temperature	
				4 [0x04]	Overvoltage	
				5 [0x05]	Undervoltage	
				6 [0x06]	Analogue input out of range error (N/A for bus interfaces)	
				7 [0x07]	Position not changing	
				8 [0x08]	Run signal overruled	
				9 [0x09]	Position initialisation not possible	
				10 [0x0A]	Parallel start-up	
				11 [0x0B]	Parallel running	
				12 [0x0C]	BLDC motor	
				13 [0x0D]	Endstop switch	
				14 [0x0E]	Parallel communication	
				15 [0x0F]	Parallel setup stopped	
				24 [0x18]	Other error	
				25 [0x19]	Position lost	
	Byte 13	Status Flags	UINT8	b0	Parallel endstop reached out	8-bit independent status indicators
				b1	Parallel endstop reached in	
				b2	Parallel running outside nominal conditions	
				b3-b7	Reserved	

## Error codes

Error	Description
0	<b>No error detected</b> No LINAK defined error detected
1	<b>'Run' command overruled</b> As a safety precaution to prevent unintentional movement at power-up, the actuator will not run until a 'Stop' command or 'Clear error' command has been sent.
2	<b>Position sensor</b> Position sensors are outside of expected operating range. VCC motor OK. Example: 10 pulses were reported on one Hall sensor and no Hall pulses on the other. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
3	<b>Overvoltage</b> Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits.
4	<b>Undervoltage</b> Input supply voltage is below operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits.
5	<b>Communication sync</b> Heartbeat from the master is not within the expected heartbeat interval. Consult the documentation for minimum requirements for heartbeat interval.
6	<b>Endstop switch (N/A for bus interfaces)</b> Endstop switches are behaving unexpectedly. Example: Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialization process by running the actuator fully extended and retracted.
7	<b>Temperature</b> Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits.
8	<b>Motor controller</b> Internal motor controller hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
9	<b>Internal power supply</b> The internal power supply is behaving unexpectedly. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
10	<b>Internal current measurement</b> Internal current reference is outside the expected limits. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
11	<b>Parallel arbitration</b> Start-up parallel configuration procedure in progress.

## Error codes

Error	Description
12	<b>Position not changing</b> Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAK or replace the product.
13	<b>Position initialisation not possible</b> Internal initialisation parameters missing. Contact LINAK.
14	<b>Alone in parallel system</b> Incorrect number of actuators in parallel system.
15	<b>Incorrect number in parallel system</b> Incorrect number of actuators in parallel system or wrongly configured
254	<b>Other internal error (Not specified)</b> Unspecified internal hardware/software error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
255	<b>Other external error (Not specified)</b> Unspecified external hardware/software error. Please inspect your application for possible issues. Send 'Clear error' command to clear error.

## Parallel error codes

Error	Description
0	<b>No error detected</b> No LINAK defined error detected
1	<b>Current overload</b> Current draw is above allowed operating limit. Reduce load, send a 'Clear error' command, and run the actuator in the opposite direction.
2	<b>Hardware</b> Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
3	<b>Temperature</b> Internal actuator temperature is above operating limit. Consult the documentation for correct temperature levels. The error will automatically be cleared when the temperature is within operating limits.
4	<b>Overvoltage</b> Input supply voltage is above operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits.
5	<b>Undervoltage</b> Input supply voltage is below operating voltage level. Consult the documentation for correct voltage levels. The error will automatically be cleared when voltage is within operating limits.



## Parallel error codes

Error	Description
6	<b>Analogue input out of range (N/A for bus interfaces)</b> Analogue input signal is outside operating limits. Servo or Proportional. Consult the documentation for correct input signal.
7	<b>Position not changing</b> Internal position sensor is behaving unexpectedly and motor might stall. Please check your application for blockage or other irregularities. If the error persists, contact LINAK or replace the product.
8	<b>Run signal overruled</b> Communication has been overruled by a higher priority input. Communication is split into the following priorities: 1. Bus communication (CAN bus, EtherNet/IP™, etc.) 2. LINAK service tool (Actuator Connect™) 3. Manual run using Red and Black wires Send a 'Clear error' command to continue.
9	<b>Position initialisation not possible</b> Internal initialisation parameters missing. Contact LINAK.
10	<b>Parallel start-up</b> Error in parallel setup. The number of connected actuators does not match your configuration. Check the configuration by using the LINAK tool Actuator Connect.
11	<b>Parallel running</b> The actuators are performing the internal setup and are not ready for operation.
12	<b>BLDC motor</b> Internal hardware error. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
13	<b>Endstop switch (N/A for bus interfaces)</b> Endstop switches are behaving unexpectedly. Both endstop switches have been activated simultaneously for more than 100 ms. Perform the initialization process by running the actuator fully extended and retracted.
14	<b>Parallel communication</b> Error in internal parallel communication. More than 5 communication errors in 500 ms. Please check the wire connections and re-power the complete setup.
15	<b>Parallel setup stopped</b> One or more actuators cannot comply with commands and stop. Master commands 'Stop' to other actuators in the network. Send 'Clear error' command to clear error. If the error persists, check your application and wire connections and re-power your complete setup.
24	<b>Other error</b> Actuator receives an undefined error code. This can be due to outdated firmware. Send 'Clear error' command to clear error. If the error persists, contact LINAK or replace the product.
25	<b>Position lost</b> Follow the relevant initialisation procedures by running the actuators from fully retracted to fully extended. If the error persists, contact LINAK or replace the product.

# Contacts

## FACTORIES

Denmark - Headquarters  
LINAK A/S  
Phone: +45 73 15 15 15  
Fax: +45 74 45 80 48  
Fax (Sales): +45 73 15 16 13  
Web: [www.linak.com](http://www.linak.com)

China  
LINAK (Shenzhen) Actuator Systems, Ltd.  
Phone: +86 755 8610 6656  
Phone: +86 755 8610 6990  
Web: [www.linak.cn](http://www.linak.cn)

Slovakia  
LINAK Slovakia s.r.o.  
Phone: +421 51 7563 444  
Web: [www.linak.sk](http://www.linak.sk)

Thailand  
LINAK APAC Ltd.  
Phone: +66 33 265 400  
Web: [www.linak.com](http://www.linak.com)

USA  
LINAK U.S. Inc.  
Americas Headquarters  
Phone: +1 502 253 5595  
Fax: +1 502 253 5596  
Web: [www.linak-us.com](http://www.linak-us.com)  
[www.linak-latinamerica.com](http://www.linak-latinamerica.com)

## SUBSIDIARIES

Australia  
LINAK Australia Pty. Ltd  
Phone: +61 3 8796 9777  
Fax: +61 3 8796 9778  
E-mail: [sales@linak.com.au](mailto:sales@linak.com.au)  
Web: [www.linak.com.au](http://www.linak.com.au)

Austria  
LINAK Zweigniederlassung - Österreich (Wien)  
Phone: +43 (1) 890 7446  
Fax: +43 (1) 890 744615  
E-mail: [info@linak.de](mailto:info@linak.de)  
Web: [www.linak.at](http://www.linak.at) - [www.linak.hu](http://www.linak.hu)

Belgium  
LINAK Actuator-Systems NV/SA  
(Belgium & Luxembourg)  
Phone: +32 (0)9 230 01 09  
E-mail: [beinfo@linak.be](mailto:beinfo@linak.be)  
Web: [www.linak.be](http://www.linak.be) - [www.fr.linak.be](http://www.fr.linak.be)

Brazil  
LINAK Do Brasil Comércio De Atuadores Ltda.  
Phone: +55 (11) 2832 7070  
Fax: +55 (11) 2832 7060  
E-mail: [info@linak.com.br](mailto:info@linak.com.br)  
Web: [www.linak.com.br](http://www.linak.com.br)

Canada  
LINAK Canada Inc.  
Phone: +1 502 253 5595  
Fax: +1 416 255 7720  
E-mail: [info@linak.ca](mailto:info@linak.ca)  
Web: [www.linak-us.com](http://www.linak-us.com)

Czech Republic  
LINAK C&S s.r.o.  
Phone: +42 058 174 1814  
Fax: +42 058 170 2452  
E-mail: [info@linak.cz](mailto:info@linak.cz)  
Web: [www.linak.cz](http://www.linak.cz) - [www.linak.sk](http://www.linak.sk)

Denmark - International  
LINAK International  
Phone: +45 73 15 15 15  
E-mail: [info@linak.com](mailto:info@linak.com)  
Web: [www.linak.com](http://www.linak.com)

Denmark - Sales  
LINAK Danmark A/S  
Phone: +45 86 80 36 11  
Fax: +45 86 82 90 51  
E-mail: [linak@linak-silkeborg.dk](mailto:linak@linak-silkeborg.dk)  
Web: [www.linak.dk](http://www.linak.dk)

Finland  
LINAK OY  
Phone: +358 10 841 8700  
E-mail: [linak@linak.fi](mailto:linak@linak.fi)  
Web: [www.linak.fi](http://www.linak.fi)

France  
LINAK France E.U.R.L  
Phone: +33 (0) 2 41 36 34 34  
Fax: +33 (0) 2 41 36 35 00  
E-mail: [linak@linak.fr](mailto:linak@linak.fr)  
Web: [www.linak.fr](http://www.linak.fr)

Germany  
LINAK GmbH  
Phone: +49 6043 9655 0  
Fax: +49 6043 9655 60  
E-mail: [info@linak.de](mailto:info@linak.de)  
Web: [www.linak.de](http://www.linak.de)

India  
LINAK A/S India Liaison Office  
Phone: +91 120 4531797  
Fax: +91 120 4786428  
E-mail: [info@linak.in](mailto:info@linak.in)  
Web: [www.linak.in](http://www.linak.in)

Ireland  
LINAK UK Limited (Ireland)  
Phone: +44 (0)121 544 2211  
Fax: +44 (0)121 544 2552  
+44 (0)796 855 1606 (UK Mobile)  
+35 387 634 6554 (Rep.of Ireland Mobile)  
E-mail: [sales@linak.co.uk](mailto:sales@linak.co.uk)  
Web: [www.linak.co.uk](http://www.linak.co.uk)

Italy  
LINAK ITALIA S.r.l.  
Phone: +39 02 48 46 33 66  
Fax: +39 02 48 46 82 52  
E-mail: [info@linak.it](mailto:info@linak.it)  
Web: [www.linak.it](http://www.linak.it)

Japan  
LINAK K.K.  
Phone: 81-45-533-0802  
Fax: 81-45-533-0803  
E-mail: [linak@linak.jp](mailto:linak@linak.jp)  
Web: [www.linak.jp](http://www.linak.jp)

Malaysia  
LINAK Actuators Sdn. Bhd.  
Phone: +60 4 210 6500  
Fax: +60 4 226 8901  
E-mail: [info@linak-asia.com](mailto:info@linak-asia.com)  
Web: [www.linak.my](http://www.linak.my)

Netherlands  
LINAK Actuator-Systems B.V.  
Phone: +31 76 5 42 44 40 /  
+31 76 200 11 10  
E-mail: [info@linak.nl](mailto:info@linak.nl)  
Web: [www.linak.nl](http://www.linak.nl)

New Zealand  
LINAK New Zealand Ltd  
Phone: +64 9580 2071  
Fax: +64 9580 2072  
E-mail: [nzsales@linak.com.au](mailto:nzsales@linak.com.au)  
Web: [www.linak.com.au](http://www.linak.com.au)

Norway  
LINAK Norge AS  
Phone: +47 32 82 90 90  
E-mail: [info@linak.no](mailto:info@linak.no)  
Web: [www.linak.no](http://www.linak.no)

Poland  
LINAK Polska  
LINAK Danmark A/S (Spółka Akcyjna)  
Phone: +48 22 295 09 70 /  
+48 22 295 09 71  
E-mail: [info@linak.pl](mailto:info@linak.pl)  
Web: [www.linak.pl](http://www.linak.pl)

Republic of Korea  
LINAK Korea Ltd.  
Phone: +82 2 6231 1515  
Fax: +82 2 6231 1516  
E-mail: [info@linak.kr](mailto:info@linak.kr)  
Web: [www.linak.kr](http://www.linak.kr)

Slovakia  
LINAK Slovakia S.R.O.  
Phone: +421 51 7563 444  
Web: [www.linak.sk](http://www.linak.sk)

Spain  
LINAK Actuadores, S.L.u  
Phone: +34 93 588 27 77  
Fax: +34 93 588 27 85  
E-mail: [esma@linak.es](mailto:esma@linak.es)  
Web: [www.linak.es](http://www.linak.es)

Sweden  
LINAK Scandinavia AB  
Phone: +46 8 732 20 00  
Fax: +46 8 732 20 50  
E-mail: [info@linak.se](mailto:info@linak.se)  
Web: [www.linak.se](http://www.linak.se)

Switzerland  
LINAK AG  
Phone: +41 43 388 31 88  
Fax: +41 43 388 31 87  
E-mail: [info@linak.ch](mailto:info@linak.ch)  
Web: [www.linak.ch](http://www.linak.ch) - [www.fr.linak.ch](http://www.fr.linak.ch)  
[www.it.linak.ch](http://www.it.linak.ch)

Taiwan  
LINAK (Shenzhen) Actuator systems Ltd.  
Taiwan Representative office  
Phone: +886 2 272 90068  
Fax: +886 2 272 90096  
E-mail: [sales@linak.com.tw](mailto:sales@linak.com.tw)  
Web: [www.linak.com.tw](http://www.linak.com.tw)

Turkey  
LINAK İth. İhr. San. ve Tic. A.Ş.  
Phone: +90 312 4726338  
Fax: +90 312 4726635  
E-mail: [info@linak.com.tr](mailto:info@linak.com.tr)  
Web: [www.linak.com.tr](http://www.linak.com.tr)

United Kingdom  
LINAK UK Limited  
Phone: +44 (0)121 544 2211  
Fax: +44 (0)121 544 2552  
E-mail: [sales@linak.co.uk](mailto:sales@linak.co.uk)  
Web: [www.linak.co.uk](http://www.linak.co.uk)

## DISTRIBUTORS

Argentina  
Novotec Argentina SRL  
Phone: 011-4303-8989 / 8900  
Fax: 011-4032-0184  
E-mail: [info@novotecargentina.com](mailto:info@novotecargentina.com)  
Web: [www.novotecargentina.com](http://www.novotecargentina.com)

Colombia  
MEM Ltda  
Phone: +[57] (1) 334-7666  
Fax: +[57] (1) 282-1684  
E-mail: [servicioalcliente@memltda.com.co](mailto:servicioalcliente@memltda.com.co)  
Web: [www.mem.net.co](http://www.mem.net.co)

India  
Mechatronics Control Equipments India Pvt Ltd  
Phone: +91-44-28558484, 85  
E-mail: [bala@mechatronicscontrol.com](mailto:bala@mechatronicscontrol.com)  
Web: [www.mechatronicscontrol.com](http://www.mechatronicscontrol.com)

Indonesia  
PT. Himalaya Everest Jaya  
Phone: +6 221 544 8956 /+6 221 544 8965  
Fax: +6 221 619 1925  
Fax (Sales): +6 221 619 4658  
E-mail: [hejplastic-div@centrin.net.id](mailto:hejplastic-div@centrin.net.id)  
Web: [www.hej.co.id](http://www.hej.co.id)

Israel  
NetivTech LTD  
Phone: +972 55-2266-535  
Fax: +972 2-9900-560  
Email: [info@NetivTech.com](mailto:info@NetivTech.com)  
Web: [www.netivtech.com](http://www.netivtech.com)

Singapore  
Servo Dynamics Pte Ltd  
Phone: +65 6844 0288  
Fax: +65 6844 0070  
E-mail: [servodynamics@servo.com.sg](mailto:servodynamics@servo.com.sg)

South Africa  
Industrial Specialised Applications CC  
Phone: +27 011 466 0346  
E-mail: [gartht@isagroup.co.za](mailto:gartht@isagroup.co.za)  
Web: [www.isaza.co.za](http://www.isaza.co.za)

United Arab Emirates  
Mechatronics  
Phone: +971 4 267 4311  
Fax: +971 4 267 4312  
E-mail: [mecatron@emirates.net.ae](mailto:mecatron@emirates.net.ae)