Actuator LA36
With CAN bus J1939 0-point
- with Software Addressing

# **Connection diagram**





## **Connection diagram**

#### 36XXXXXXXX17XX-XXXXXXXXXXXXXX

<b>\</b> +	24/48 VDC +	BROWN	Power 2	AMP De	utsch
-\	GND -	BLUE	1		
	Not to be connected	ORANGE	Signal 5	AMP	-1 ))
	Digital input	RED	1	Deutsch	-1
	Digital input	BLACK	2		
	Not to be connected	LIGHT BLUE	6		
	Bus	YELLOW	3		
SAE J1939	Bus	GREEN	4		
	Not to be connected	GREY	0		
	Data	VIOLET	7		
Service- Interface	Data GND	WHITE	8		



### The BusLink software tool is available for CANbus actuators and can be used for:

Diagnostics, manual run and configuration

The newest version is available online at LINAK.COM/TECHLINE



Please note: The BusLink configuration cable must be purchased separately Item number for BusLink cable kit: 0367997 (adapter + USB2Lin)

## I/O specifications

## CAN bus (J1939) 0-Point with Software Addressing

Input/Output	Specification			ation	Comments
Description	Compatible with the SAE J1939 standard. Uses CAN messages to command move¬ment, setting parameters and to deliver feedback from the actuator. See the LINAK CAN bus user manual. Actuator identification is provided, using standard J1939 SW addressing.				CAN SAE J1939
Brown Connect to positive	12 VDC, current limit 30 A 24 VDC, current limit 20 A 48 VDC, current limit 8 A				Note: Do not swap the power supply polarity on the brown and blue wires!  The PCB is coupled to the housing through
	Vsup	Vmin	Vmax		a capacitor.  Current limit levels can be adjusted through
		10,5 V	16 V	Motor running	Actuator Connect®.
	12 V	6 V	16 V	Motor not running CAN communication possible	If the temperature drops below 0 °C, all current limits will automatically increase with a factor 2.
	24 V	18 V	32 V	Motor running	
		10 V	32 V	Motor not running CAN communication possible	
	48 V	34 V	58 V	Motor running	
		24 V	60 V	Motor not running CAN communication possible	
	1 1				
Blue Connect to negative	- (GND)				
Orange	Not to be used				
Red	Extends the actuator				The signal becomes active at: > 67% of V <sub>IN</sub>
Black	Retracts the actuator				The signal becomes inactive at: < 33% of V <sub>IN</sub>
1: 1: 5!	Not to be used				Input current: 10 mA
Light Blue	Not to be used				Not to be used

TECHLINE

Input/Output	Specification	Comments	
Green	CAN II	Actuators with CAN bus does not contain the 120 Ω terminal resistor. The physical layer is in accordance with J1939-15. * Speed: Autobaud up to 500 kbps Max bus length: 40 meters Max stub length: 3 meters	
Yellow	CAN_H	Max node count: 10 (can be extended to 30 under certain circumstances) Wiring: Unshielded twisted pair	
Violet	Service interface	Only Actuator Connect® can be used as service interface. Use grey adapter cable	
White	Service interface GND		

#### Terms of use

Terms of use
LINAK® takes great care in providing accurate and up-to-date information on its products. However, the
user is responsible for determining the suitability of LINAK products for a specific application.
Due to continual development, LINAK products are subject to frequent modifications and changes.
LINAK reserves the rights to conduct modifications, updates, and changes without any prior notice. For
the same reason, LINAK cannot guarantee the correctness and actual status of imprinted information on
its products.

LINAK uses its best efforts to fulfil orders. However, for the reasons mentioned above, LINAK cannot guarantee availability of any particular product at any given time. LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or in other written material created and produced by LINAK, LINAK subsidiaries, or LINAK affiliates.

All sales are subject to the 'Standard Terms of Sale and Delivery for LINAK A'S' available on LINAK websites. LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

